

An analyst's guide to precision

Analytical Methods Committee, AMCTB No. 70



shortfall may be the cause of the frequently-disappointing performance obtained from procedures taken from the literature. A convenient way to estimate $\sigma_{\rm r}$ is a within-run duplication of typical test materials.

10 10 10

Analytical Methods AMC Technical Briefs

application sectors. The function $\sigma = \sqrt{\alpha^2 + (\beta_-)^2}$, for concentration with adjustable parameters α , β , has been found to fit standard deviations from particular procedures in many different types of analysis and conditions of measurement.

F /c

Standard deviations estimated from a small number of results are themselves very variable. The commonly-used sample size of ten results is 'small' in this context: it gives standard deviations with their own relative standard error of 22%, so estimates could easily be as low as 0.5 times, or as high as 1.5 times, the true value. Standard deviations calculated from even smaller numbers of results should be treated with suitable caution.

10 10

This Technical Brief was prepared by the Statistical and Validation Subcommittees, and approved for publication by the Analytical Methods Committee on 17/08/15.



